

	Prime Basic	Prime Advance	Prime Expert	Prime Hybrid	Prime Trial
iMrs prime Control Unit	✓	✓	✓	✓	✓
IMRS prime Connector Box	✓	✓	✓	✓	✓
Exagon Applicator Mat	✓	✓	✓	✗	✗
Exagon Applicator Pad	✓	✓	✓	✓	✓
Exagon Applicator Spot	✗	✓	✓	✓	✓
Exagon Applicator FIR	✗	✗	✗	✓	✓
20-Pin prime Connector Cable	✓	✓	✓	✓	✓
Software Tool Fast Start Program	✓	✓	✓	✓	✓
Software Tool Manual Operation	✓	✓	✓	✓	✓
Software Tool Program Mode	✗	✓	✓	✓	✓
Software Tool Split Mode	✗	✗	✓	✓	✓
Software Tool iGUIDE	✗	✗	✓	✓	✓
Software Tool Hybrid Control	✗	✗	✗	✓	✓
Software Tool Frequency Generator	✗	✗	✗	✗	✓